

# Cutting Guidelines for Obstructions



- Measure and mark section of cladding to be removed to fit around obstruction.
- **BEFORE** cutting, drill hole (3/8" recommended) at each intersection to avoid risk of panel fractures

