


# Flag Mount To Panel \* PREFERRED MOUNTING \*

Flags are installed after column cladding is in place.



SK-04816


Questions? Call 800-228-8925

# Flag Mount To Seam

\* ALTERNATE MOUNTING \*

USE WHEN THE PREFERRED MOUNTING IS NOT SUITABLE.

Flags are installed after column cladding is in place.



SK-04816

Questions? Call 800-228-8925